



Installation Instructions

DD-TDO-JK4-07

JEEP JK WRANGLER UNLIMITED
OLYMPIC TUBE DOOR NETTING
2007 UP

BEFORE YOU PROCEED WITH THE INSTALLATION LAY OUT THE NETTING ON TOP EACH TUBE DOOR TO BE SURE YOU ARE PUTTING THE CORRECT PIECE ON EACH DOOR. THE HARD WARE FOR THE TUBE DOOR SHOULD NOT BE INSTALL UNTIL THE NETTING IS INSTALLED.



CAREFULLY SLIDE THE TOP TUBE THROUGH THE SEWN LOOPS AS SHOWN IN THE PICTURES BELOW



THE TUBE DOOR SHOULD LOOK LIKE THIS ONCE THE TUBE IS PUT THROUGH ALL THE LOOPS



TURN THE DOOR OVER AND PUT THE LOOSE END OF THE STRAP THROUGH THE LADDER LOC BUT DO NOT TIGHTEN THE STRAPS AT THIS TIME. THE DOOR MUST BE INSTALLED FIRST AND THEN THE STRAPS CAN BE TIGHTENED UP. FOLLOW THIS PROCEDURE FOR EACH DOOR.



Dirtydog 4x4
3045 Southcreek Road
Mississauga, ON
Canada
1.855-704-0708
Question? Call or email orderdesk@dirtydog4x4.com